

LED ΦΩΤΙΣΤΙΚΑ ΔΡΟΜΟΥ

146-57161 έως 146-57176

EUROLAMP®

⚠ Συστάσεις ασφαλείας

Είναι απαραίτητο να διαβάσετε και να κατανοήσετε όλες τις οδηγίες ασφάλειας και λειτουργίας πριν από τη εγκατάσταση του φωτιστικού. Εάν το φωτιστικό χρησιμοποιείται για πρώτη φορά, διατηρήστε τις οδηγίες ασφαλείας για μελλοντική αναφορά.



Για την εγκατάσταση του φωτιστικού απευθυνθείτε σε έμπειρο ηλεκτρολόγο όπου θα βεβαιώσει πως η εγκατάσταση του θα πραγματοποιηθεί σύμφωνα με τις απαιτούμενες διατάξεις. Η λανθασμένη εγκατάσταση και χρήση μπορούν να προκαλέσουν κίνδυνο ηλεκτροπληξίας ⚡ ή πυρκαγιάς.

Τα LED φωτιστικά που δεν χρησιμοποιούν λαμπτήρες φωτισμού, στο τέλος της διάρκειας ζωής τους πρέπει να αντικαθίστανται ολόκληρα. Σε αυτή την περίπτωση μην προσπαθήσετε να ανοίξετε-τροποποιήσετε το φωτιστικό.

Η εγγύηση δεν ισχύει πλέον όταν υπάρχουν ελαττώματα στο προϊόν που προέρχονται από ζημιά ή όταν τα μέρη του προϊόντος έχουν αλλιωθεί από μη εξουσιοδοτημένα άτομα καθώς και μετά από τυχόν επέμβαση στο περιεχόμενο της συσκευής από ακατάλληλο χειρισμό ή κακή χρήση.

Ακολουθήστε τις παρακάτω οδηγίες για την ασφαλή χρήση και εγκατάσταση του φωτιστικού. Καθώς θα αποσυσκευάζετε το προϊόν, ελέγξτε για ζημιές. Σε αυτή την περίπτωση ενημερώστε τον προμηθευτή σας.

Εγκατάσταση

Ακολουθείστε τις παρακάτω οδηγίες για την ασφαλή τοποθέτηση και εγκατάσταση. Η εγκατάσταση απαιτεί ασφαλείς χειρισμούς ώστε να αποφευχθεί πιθανή ζημιά-φθορά προκαλώντας μείωση της απόδοσης του φωτιστικού ή και της ασφαλούς λειτουργίας

1. Πριν ξεκινήσετε βεβαιωθείτε και ελέγξτε πως έχετε κλείσει την παροχή ρεύματος στο σημείο όπου θα τοποθετήσετε το προϊόν.
2. Συνδέστε την καλωδίωση του φωτιστικού, σε αυτή της παροχής (230V). (Συνιστάται η εγκατάσταση από εξειδικευμένο τεχνικό)
3. Βεβαιωθείτε πως οι συνδέσεις δεν είναι χαλαρές.
4. Στερεώστε το φωτιστικό στο σημείο επάνω στον βραχίονα και έπειτα ανοίξτε την παροχή ρεύματος.

*Το φωτιστικό σας είναι κλάσης μόνωσης "I" και χρησιμοποιείται η καλωδίωση της γείωσης, θα πρέπει να κάνετε τις αντίστοιχες συνδέσεις ώστε το φωτιστικό να γειώνεται.

Η EUROLAMP ABEE διατηρεί το δικαίωμα να ερμηνεύει και να τροποποιεί το περιεχόμενο αυτού του εγγράφου ανά πάσα στιγμή χωρίς προηγούμενη ειδοποίηση.



Η σήμανση υποδηλώνει ότι το προϊόν δεν πρέπει να απορρίπτεται μαζί με οικιακά απορρίμματα σε ολόκληρη την Ευρωπαϊκή Ένωση. Ανακυκλώστε τα εξαρτήματα και μέρη του προϊόντος, επιστρέψτε την χρησιμοποιημένη συσκευή, χρησιμοποιήστε το σύστημα συλλογής ή επικοινωνήστε με το μεταπωλητή από τον οποίο αγοράσατε το προϊόν.

CE IP66

ΚΑΤΑΣΚΕΥΑΖΕΤΑΙ / ΕΙΣΑΓΕΤΑΙ ΑΠΟ: EUROLAMP ABEE, 3ο χλμ. ΣΥΜΜΑΧΙΚΗΣ ΟΔΟΥ, 57013 ΩΡΑΙΟΚΑΣΤΡΟ, ΘΕΣΣΑΛΟΝΙΚΗ, Τ: 2310 574802
ΚΑΤΑΣΚΕΥΑΖΕΤΑΙ ΣΤΗΝ ΚΙΝΑ
info@eurolamp.gr • www.eurolampglobal.com

LED STREET LIGHTS

146-57161 until 146-57176

EUROLAMP®

⚠ Safety recommendations

It is essential to read and understand all the safety and operating instructions before the installation of the streetlight. If this is your first time using the streetlight, keep the instructions secure for future reference.



For the installation of the streetlight, consult a qualified electrician to confirm that the installation will be carried out in accordance with the required provisions. Improper installation and use may result in electric shock ⚡ or fire.

The LED streetlights that they are not using lighting bulbs, at the end of the self-life they must be fully replaced. In this case, do not attempt to open or modify the streetlight

The warranty is no longer valid when there are defects in the product where come from damages or when the parts of the product has been damaged by unauthorized persons as well as after any intervention on the device due improper handling or misuse.

Follow the instructions below for safe use and installation of the streetlight. As you unpacking the product, check for damages. In that case, please inform your supplier.

Installation

Follow the instructions below for safe installation. The installation requires safe and proper handling in terms of avoiding potential damage of the streetlight causing reduction of efficacy and alteration in safety.

1. Before you start, check and be sure that you have turn off the power supply at the point which you will place the product.
2. Make the connection between the streetlight and power supply wiring (230V). (It is recommended that the installation has to be carried out by an electrician)
3. Be sure that the connections are not less tight.
4. Clamp the streetlight on the bracket and then turn on the power supply.

*The street light is insulation class "I" and the ground wire used. You should make the connections accordingly, so the streetlight be grounded.

EUROLAMP SA reserves the right to interpret and amendment the content of this document at any time without prior notice.



The marking indicates that the product should not be disposed of with household waste throughout the European Union. Recycle components and parts of the product, return used device, use a collection system or contact with the reseller you have purchased the product.

CE IP66

MANUFACTURED / IMPORTED BY: EUROLAMP SA, 3rd km SYMMACHIKI ROAD, 57013 ORAIOKASTRO, THESSALONIKI, GREECE, T: +30 2310 574802
MADE IN CHINA
info@eurolamp.gr • www.eurolampglobal.com